

	<b>Operation manual</b> <b>操作手册</b>	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	1 / 110



<b>Project No.</b>	6066
<b>Equipment</b>	Sachet cartoner packing line
<b>Model</b>	40CPM
<b>Series No.</b>	VAN256066

### Version History

Version	Issued date	Reason for issue
V 1.0	5-Aug-25	Initial issue

	<b>Operation manual</b> <b>操作手册</b>	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	1 / 110

## Contents

<b>1. Equipment safety matters</b> .....	<b>1</b>
1.1 overview .....	1
1.2 Use it correctly .....	1
1.3 Transport and installation.....	1
1.4 staff member .....	2
1.5 Operation, maintenance and handling .....	2
1.6 Other hazards .....	4
<b>2. Equipment and operating environment</b> .....	<b>5</b>
2.1 Power requirements .....	5
2.2 Device power .....	5
2.3 Detect before powering on.....	5
<b>3. Device touch interface</b> .....	<b>6</b>
3.1 User permission login interface .....	6
3.2 Status bar .....	7
3.3 Main screen .....	8
3.4 Servo control interface.....	10
3.5 Manual control interface .....	24
3.6 Parameter setting interface.....	25
3.7 Input information interface .....	27
3.8 Output information interface.....	29
3.9 Function Settings Interface .....	31
3.10 Recipe management interface .....	33
<b>4. Fault information and handling methods</b> .....	<b>34</b>
4.1 Fault information interfaceFigure4-1-1.....	34
4.2 HMI fault information list .....	35
4.3 HMI fault information description .....	38
<b>5. Servo drive fault code query table</b> .....	<b>39</b>
5.1 Faults and Warnings.....	39
5.2 Communication faults and warning codes.....	44
5.3 Solutions to faults.....	50
<b>6. Paper box requirements</b> .....	<b>63</b>
6.1 Shape and size .....	63
6.2 Storage and use.....	67
<b>7. Operation parameters</b> .....	<b>68</b>
7.1 Cboost-8pcs.....	68
7.2 Cboost-10pcs.....	75
7.3 Cboost-15pcs.....	81
7.4 Fibotax-10pcs.....	88

	<b>Operation manual</b> <b>操作手册</b>	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	2 / 110

7.5 Simfex-15pcs.....	94
7.6 Manual line.....	101

	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	1 / 110

# 1. Equipment safety matters

## 1.1 overview

1. In addition to reading the safety rules, every transportation, loading and unloading, operation and maintenance personnel must read the relevant content in the manual.
2. The manual must be placed in a place commonly used by the relevant personnel, such as in the designated toolbox or tool bag.
3. All work must comply with the terms of the manual.
4. All kinds of safety, danger, operation and protection signs on the machine must be complete and clear.
5. If there are any additional safety clauses in the contract, they must also be complied with.

## 1.2 Use it correctly

1. It must be used in accordance with the conditions indicated and required by the manual, and the user must have full safety awareness.
2. Any unsafe factors affecting the machine should be corrected immediately.
3. It must be strictly implemented in accordance with the installation, disassembly, use, operation, maintenance and repair instructions formulated by the manufacturer to ensure proper use.

## 1.3 Transport and installation

1. Read and follow the following instructions before lifting the machine
2. Due to design requirements, the center of gravity of the machine is inside the machine.
3. Use ropes and hooks with sufficient capacity.
4. Use a rope of sufficient length.

	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	2 / 110

5. Check the rope guidance on the lifting device according to the hoist specifications

## 1.4 staff member

1. The personnel entrusted with the work must be familiar with this use and maintenance manual, especially the safety manual. There are the same requirements for those who work on the machine, when necessary, such as maintenance personnel who come to replace gears.
2. For safety's sake, long hair must be tied back, and clothes must be tight without jewelry to prevent injury.
3. Only use personnel with good quality and responsibility to be responsible for operation, assembly, maintenance and repair.
4. People who have not been trained, trained or guided by experienced personnel are not allowed to engage in start-up work.
5. That personal protection equipment required in accordance with the rules or "use and maintenance instructions" should be used.
6. The operator should ensure that the machine is not operated by unauthorized personnel.

## 1.5 Operation, maintenance and handling

1. The safety and accident prevention procedures of the country where the equipment is installed are adapted to the operation of the machine.
2. The machine can only be operated under the following circumstances:
  - Equipped with all protective equipment
  - There is an "emergency stop" device

The above equipment must be guaranteed to be effective and fully functional.

3. The power connection must be completed by a qualified person.
4. Any construction of electrical components or materials can only be carried out by

	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	3 / 110

trained electricians or under the supervision of trained electricians in accordance with relevant regulations.

5. All control devices and "emergency stop" devices must be checked in advance before operation.

6. Before starting work, be familiar with the environment and situation around you, such as obstacles in the work area.

7. The operator must make sure that there is no one in the working area when starting.

8. Every situation mentioned in the safety regulations must be avoided! Tasks that have not been considered for security cannot be carried out!

9. Any operation that may cause harm to the machine must be avoided.

10. In case of operation error, stop immediately and prevent restart. Correct the mistake immediately.

11. Check the external visual damage and fault of the machine at least once per shift. If necessary, it should be shut down immediately and prevent restart.

12. Must comply with the starting alarm device and control display.

13. The machine must be turned on and off in the manner specified in the operation instructions of the "Use and Maintenance Instructions".

14. If the machine fails to work normally due to a safety failure at work, it should be stopped immediately and reported to the management department and personnel.

15. Regular inspection and maintenance must be carried out in accordance with the provisions of the "Use and Maintenance Instructions".

16. Fully guarantee maintenance within the safe range.

17. The modification, modification and addition of new functions to the machine will affect safety, so it must not be implemented without the permission of the manufacturer.

18. Before starting work, maintenance or repair, the situation must be briefly introduced to the operator, and a special person must be appointed to supervise the process.

19. The machine works on electricity. If it is not skilled, it may bring serious or disastrous consequences for illegal operation and repair.

	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	4 / 110

20. The isolation switch must be disconnected before the machine is repaired to prevent accidental restart.

21. All pneumatic parts must be operated by personnel with aerodynamic knowledge and experience!

22. Please release the pressure (compressed air) in the component pipe before construction!

23. When handling lubricating oil, detergents or other chemicals, it should be used with reference to the relevant safety materials of this product and comply with the safety instructions of applicable food machinery standards.

## 1.6 Other hazards

This section outlines the dangers that may arise during transportation, storage, installation, operation, disassembly, maintenance and repair.

### 1. Mechanical danger

- Squeeze or cut off people's limbs between machine parts or between the mold releaser and the surrounding objects.

- Pinched or strained by rollers, gear wheels, conveying devices and pneumatic devices.

- The machine slid down or moved unexpectedly.

- The machine is not stable enough.

### 2. Electrical hazards

- The cable is damaged.

### 3. Pneumatic danger

- Clamped by a pneumatic device.

### 4. Dangers caused by temporary failure of mechanical protection

- Remove the protective device or control device during the maintenance process.

	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	5 / 110

In order to eliminate the above dangers, the safety instructions in the "Usage and Maintenance Instructions" must be strictly followed.

## 2. Equipment and operating environment

### 2.1 Power requirements

The power supply voltage adopts three-phase 220V and is converted into three-phase 380V through the transformer.

### 2.2 Device power

--Total power of equipment: see electrical schematic diagram

--Equipment power supply voltage: three-phase system (220V AC)

### 2.3 Detect before powering on

1. The bumps of the equipment during transportation may cause some screws of electrical components to be loose. Before the equipment is sent, please check whether the screws of all electrical components are loose and tighten the screws.
2. Check whether the equipment line is complete
3. Check whether the three-phase power supply is connected correctly (the grounding resistance should not exceed  $4\Omega$ )







	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	6 / 110

### 3. Device touch interface

#### 3.1 User permission login interface



Interface explanation:

No.	Description	Refer to picture	Explanation
1	Login blank 		User login information
			User option
			Password input
			Confirm
			Cancel
2	Language chooses	N/A	Click the language







	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	8 / 110


2. The operating status of the device

3. Current system time





### 3.3 Main screen



No.	Description	Refer to picture	Explanation
1	Main screen 		Click relative button on the bottom bar, display main screen.
2	Language chooses 	N/A	Click the language option to switch the corresponding language.



Device start-up process: The device runs according to the flow chart shown above. On the main screen, you can click the left button to start the device.


NO.	Description	Refer to picture	Explanation
1	Left suction head A paid, left suction head B paid, right suction head A paid, right suction head B paid		real-time display of the material bag of 4 suction heads.
2	The bar chart on the left		shows the number of loading packages placed in the current workstation, and the reset button can clear the record when it is down.
3	The grid table on the right		shows whether there is a material package of the feeding workstation, the inspection of the material suction box record, and the box record of the box workstation with the box.
4	Manual pushing number		In the mode of manual packaging,

	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	10 / 110




			the current number of pushing is displayed and the number of pushing is set.
--	--	--	--

### 3.4 Servo control interface

- Virtual axis servo
- 



Before simple manual operation can be carried out in the manual mode stop state of the equipment, it is necessary to set the debugging parameters, such as the electric forward and reverse rotation of the servo motor and the operating distance of one station.

NO.	Description	Refer to picture	Explanation
1	Servo speed		the cycle running speed after the coupling of each axis in time
2	Acceleration		start-stop acceleration after coupling of each axis in time
3	Go to one station		A station changes at the relevant position of the virtual axis

	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	11 / 110

4	Forward / Reverse Rotation of the Virtual Axis		The virtual axis rotates according to the set operating speed
---	--	--	---








## Box servo

Mode: not connected    Status: not connected

Commissioning parameters such as electric forward and reverse rotation of servo motors and parameter setting are required before simple manual operation can be carried out in manual mode and stop state.

NO.	Description	Refer to picture	Explanation
1	Not synchronized		Whether the current real axis is bound to the virtual axis.
2	Servo speed		single-axis jog speed in manual mode stops.
3	Acceleration and deceleration speed		The acceleration and deceleration of single-axis jogs in the manual mode stop state, and the acceleration of the virtual axis after synchronization.

	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	12 / 110

4	Zero search speed		After finding the reference point switch, the servo motor slows down and positions the speed at the reference point position.
5	Origin offset		Refers to the zero-position offset value input.
6	Torque limit		The limit value of the current motor torque.
7	Forward		the current real axis jogs the forward rotation button.
8	Backward		The current solid axis jogging the reversal button.
9	Find Zero		The current solid axis is looking for the reference point operation.
	Coupling		The current real axis is bound to the virtual axis.

- Workstation servo













Commissioning parameters such as electric forward and reverse rotation of servo motors

and parameter setting are required before simple manual operation can be carried out in manual mode and stop state.

Mode: not connected    Status: not connected

Not synchronized    Workstation servo A		Not synchronized    Workstation servo B		
current location	##### °	Current speed	##### °/s	Virtual axis
Current torque	##### %	Current torque	##### %	Box servo
speed	##### °/s	Acc/Dec	##### °/s <sup>2</sup>	Feeding station
Zero search speed	##### °/s	Creep speed	##### °/s	Pushing servo
Origin Offset	##### °	Torque limit	##### %	Box opening servo
Forward    Backward    Find Zero		Forward    Backward		Box receiving servo
coupling		Bag pressing cylinder    Push bag cylinder		Bag retrieval servo
				Bag delivery servo
				Bag delivery servo
Main screen	Manual Control	Servo control	Parameter	I/O
				Recipe
				Function settings
				LogIn
				Fault monitoring

	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	14 / 110

NO.	Description	Refer to picture	Explanation
1	Not synchronized		Whether the current real axis is bound to the virtual axis.
2	Servo speed		single-axis jog speed in manual mode stops
3	Acceleration and deceleration speed		The acceleration and deceleration of single-axis jogs in the manual mode stop state, and the acceleration of the virtual axis after synchronization
4	Zero search speed		After finding the reference point switch, the servo motor slows down and positions the speed at the reference point position.
5	Origin offset		Refers to the zero-position offset value input.
6	Torque limit		The limit value of the current motor torque.
7	Forward		the current real axis jogs the forward rotation button.
8	Backward		The current solid axis jogging the reversal button
9	Find Zero		The current solid axis is looking for the reference point operation.
10	Coupling		The current real axis is bound to the virtual axis.
11	Bag pressing cylinder		realize the action and retraction of the bag pressure cylinder.
12	Push bag cylinder		realize the action and retraction of the bag pushing cylinder.

- Pushing servo

Mode: not connected    Status: not connected

### Pushing servo

current location	##### mm	Current speed	##### mm/s	Current torque	##### %
Manual Speed	##### mm/s	Automatic speed	##### mm/s	Acc/Dce	##### mm/s <sup>2</sup>
Automatic speed	##### mm/s	Wait position	##### mm	Push material position	##### mm
Torque limit	##### %				

Forward

Backward

Find Zero

Wait position

Push material position

Bag pressing cylinder

Left ear cylinder

Right ear cylinder

Virtual axis

Box servo

Feeding station

Pushing servo

Box opening servo

Box receiving servo





Bag retrieval servo












Bag delivery servo

Bag delivery servo


Main screen
Manual Control
Servo control
Parameter
I/O
Recipe
Function settings
LogIn
Fault monitoring

Commissioning parameters such as electric forward and reverse rotation of servo motors and parameter setting are required before simple manual operation can be carried out in manual mode and stop state.








NO.	description	Refer to picture	explanation
1	Manual speed		The speed of the unit axis jog in the manual mode stopped state.
2	Feeding speed		The speed of a single axis from the waiting position to the pushing position in the stop state of manual mode, and the acceleration of the virtual axis after synchronization.
3	Return speed		In the manual mode stop state, the single axis returns from the push position to the waiting position speed, and runs at the acceleration of the virtual axis after synchronization.
4	Acceleration and deceleration speed		The acceleration and deceleration of single-axis jogs in the manual mode stop state, and the acceleration of the virtual axis after synchronization.

5	Torque limit		The limit value of the current motor torque.
6	Servo waiting position		The position where the servo motor is waiting for the push on a single axis.
7	Servo pushing position		The position where the servo motor single-axis pushing is completed.
8	Forward		the current real axis jogs the forward rotation button.
9	Backward		The current solid axis jogging the reversal button.
10	Zero finding		The current solid axis is looking for the reference point operation.
11	Waiting position		The current real axis is positioned and waiting position according to the position of the imaginary axis.
12	Push material position		The current solid shaft positions the push material according to the position of the virtual axis.
13	Bag pressing cylinder		realize the action and retraction of the bag pressure cylinder.
14	Left ear cylinder		realize the action and retraction of the left open ear cylinder.
15	Right ear cylinder		realize the action and retraction of the right open ear cylinder.






- Box opening servo



Commissioning parameters such as electric forward and reverse rotation of servo motors and parameter setting need to be set before simple manual operation can be carried out when the equipment is stopped in manual mode.

NO.	Description	Refer to picture	Explanation
1	Not synchronized		Whether the current real axis is bound to the virtual axis.
2	Auto Speed		The speed at which it runs in automatic mode.
3	Acceleration and deceleration speed		The acceleration and deceleration of single-axis jogs in the manual mode stop state, and the acceleration of the virtual axis after synchronization.
4	Torque limit		The limit value of the current motor torque.
5	Origin Offset		Input the offset value of the origin position.
6	Pick up box position		The position of the box pick-up action
7	Forward		the current real axis jogs the forward rotation button.

	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	18 / 110

8	Backward		The current solid axis jogging the reversal button.
9	Find Zero		The current solid axis is looking for the reference point operation.
10	Coupling		The current real axis is bound to the virtual axis.
11	Sucker		Suction cup cylinder opening and closing.
12	Back flush		blow back cylinder opening and closing.

- Box receiving servo

Mode: not connected    Status: not connected

Not synchronized

### Box receiving servo

current location <input type="text" value="##### mm"/>	Current speed <input type="text" value="##### mm/s"/>	Current torque <input type="text" value="##### %"/>
Automatic speed <input type="text" value="##### mm/s"/>	Acc/Dec <input type="text" value="##### mm/s&lt;sup&gt;2&lt;/sup&gt;"/>	Torque limit <input type="text" value="##### %"/>
Origin Offset <input type="text" value="##### mm"/>	Box connection position <input type="text" value="##### mm"/>	Box placement position <input type="text" value="##### mm"/>

Virtual axis

Box servo

Feeding station

Pushing servo

Box opening servo

Box receiving servo

Bag retrieval servo

Bag delivery servo













Bag delivery servo

Main screen
Manual Control
Servo control
Parameter
I/O
Recipe
Function settings
LogIn
Fault monitoring

Commissioning parameters such as electric forward and reverse rotation of servo motors and parameter setting need to be set before simple manual operation can be carried out when the equipment is stopped in manual mode.

NO.	Description	Refer to picture	Explanation
1	Not Synchronized	Not synchronized	Whether the current real axis is bound to the virtual axis.

	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	19 / 110








2	Auto Speed		The speed at which it operates in automatic mode.
3	Acceleration and deceleration speed		The acceleration and deceleration of single-axis jogs in the manual mode stop state, and the acceleration of the virtual axis after synchronization.
4	Origin Offset		Input the offset value of the origin position.
5	Torque limit		The limit value of the current motor torque.
6	Box receiving servo		the position of the box receiving action
7	Box placement position		The position of the box placement
8	Forward		the current real axis jogs the forward rotation button.
9	Backward		The current solid axis jogging the reversal button.
10	Find zero		The current solid axis is looking for the reference point operation.
11	Coupling		The current real axis is bound to the virtual axis.
12	Sucker		opening and closing of the box of the vacuum air cylinder.
13	Backflush		The opening and closing of the box blow back cylinder.

- Take the bag servo



Mode: not connected Status: not connected

Left bag take servo				Right bag take servo				
current location	##### °	Current speed	##### °/s	current location	##### °	Current speed	##### °/s	Virtual axis
Current torque	##### %			Current torque	##### %			Box servo
Manual speed	##### °/s			Manual speed	##### °/s			Feeding station
Automatic speed	##### °/s	Acc/Dec	##### °/s <sup>2</sup>	Automatic speed	##### mm	Acc/Dec	##### °/s <sup>2</sup>	Pushing servo
Origin Offset	##### °	Torque limit	##### %	Origin Offset	##### °	Torque limit	##### %	Box opening servo
Forward			Backward			Find Zero		Box receiving servo
Suction cup A		Blow back A		Suction cup A		Blow back A		Bag retrieval servo
Suction cup B		Blow back B		Suction cup B		Blow back B		Bag delivery servo
Zero search completed Need to suction head A upwards				Zero search completed Need to suction head A upwards				Bag delivery servo
Main screen	Manual Control	Servo control	Parameter	I/O	Recipe	Function settings	LogIn	Fault monitoring

Commissioning parameters such as electric forward and reverse rotation of servo motors and parameter setting need to be set before simple manual operation can be carried out when the equipment is stopped in manual mode.

NO.	Description	Refer to picture	Explanation
1	Manual speed		The speed of the unit axis jog in the manual mode stopped state.
2	Auto Speed		The speed at which it operates in automatic mode.
3	Acceleration and deceleration speed		The acceleration and deceleration of single-axis jogs in the manual mode stop state, and the acceleration of the virtual axis after synchronization.
4	Torque limit		The limit value of the current motor torque.
5	Forward		the current jogging forward rotation button with box A solid shaft and box B solid shaft.
6	Backward		The current jogging reversal button with box A solid shaft and box B solid axis.
7	Find Zero		The current operation of finding the reference point between the solid axis with box A and the solid axis with box B.

	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	21 / 110




8	Suction cup		opening and closing of the vacuum air cylinder for bagging.
9	Blow back		the opening and closing of the bag blow back cylinder.







## Bag delivery servo

Mode: not connected    Status: not connected

Left bag delivery servo				Right bag delivery servo				
current location	##### mm	Current speed	##### mm/s	current location	##### mm	Current speed	##### mm/s	Virtual axis
Current torque	##### %			Current torque	##### %			Box servo
Manual speed	##### mm/s			Manual speed	##### mm/s			Feeding station
Automatic speed	##### mm/s	Acc/Dec	##### mm/s <sup>2</sup>	Automatic speed	##### mm/s	Acc/Dec	##### mm/s <sup>2</sup>	Pushing servo
Bag delivery distance	##### mm	Torque limit	##### %	Bag delivery distance	##### mm	Torque limit	##### %	Box opening servo
Bag delivery distance	##### mm							Box receiving servo
Forward			Backward			Sending bags		Bag retrieval servo
Forward rotation			Backward			Sending bags		Bag delivery servo
								Bag delivery servo
Main screen	Manual Control	Servo control	Parameter	I/O	Recipe	Function settings	LogIn	Fault monitoring

Commissioning parameters such as electric forward and reverse rotation of servo motors and parameter setting are required before simple manual operation can be carried out in manual mode and stop state.

NO.	Description	Refer to picture	Explanation
1	Manual speed		The speed of the unit axis jog in the manual mode stopped state.
2	Auto Speed		The speed at which it operates in automatic mode.
3	Acceleration and deceleration speed		The acceleration and deceleration of single-axis jogs in the manual mode stop state, and the acceleration of the virtual axis after synchronization.

4	Bag delivery distance		The distance of the bag feeding action.
5	Torque limit		The limit value of the current motor torque.
6	Number of bag feeds		Count the number of times the bag delivery action is performed.
7	Forward		the current jogging forward rotation button with box A solid shaft and box B solid shaft.
8	Backward		The current jogging reversal button with box A solid shaft and box B solid axis.
9	Sending bags		Perform the bag feeding action.

- Up Down servo











Mode: not connected    Status: not connected

Left UpDown Servo				Right UpDown Servo				
current location	##### mm	Current speed	##### mm/s	current location	##### mm	Current speed	##### mm/s	Virtual axis
Current torque	##### %			Current torque	##### %			Box servo
Manual speed	##### mm/s	Acc/Dec	##### mm/s <sup>2</sup>	Manual speed	##### mm/s	Acc/Dec	##### mm/s <sup>2</sup>	Feeding station
Automatic speed	##### mm/s	Torque limit	##### %	Automatic speed	##### mm/s	Torque limit	##### %	Pushing servo
Bag-taking position	##### mm	Origin Offset	##### mm	Bag-taking position	##### mm	Origin Offset	##### mm	Box opening servo
Descending position	##### mm	Put bag position	##### mm	Descending position	##### mm	Bag delivery distance	##### mm	Box receiving servo
Forward			Backward			Home		Bag retrieval servo
Bag-taking position		Put bag position		Bag-taking position		Put bag position		Bag delivery servo
Bag delivery servo		Bag delivery servo		Bag delivery servo		Bag delivery servo		
Main screen	Manual Control	Servo control	Parameter	I/O	Recipe	Function settings	LogIn	Fault monitoring

Commissioning parameters such as electric forward and reverse rotation of servo motors and parameter setting are required before simple manual operation can be carried out in manual mode and stop state

NO.	Description	Refer to picture	Explanation
-----	-------------	------------------	-------------



	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	23 / 110

1	Manual speed		The speed of the uni axis jog in the manual mode stopped state.
2	Auto Speed		The speed at which it operates in automatic mode Acceleration and deceleration speed: single-axis jog acceleration and deceleration speed in manual mode stop.
3	Torque limit		The limit value of the current motor torque.
4	Descendant		Servo picking to complete the descent distance.
5	Origin Offset		Input the offset value of the origin position.
6	Forward		the current jogging forward rotation button with box A solid shaft and box B solid shaft.
7	Backward		The current jogging reversal button with box A solid shaft and box B solid axis.
8	Home		The servo finds the origin according to the set parameters.
9	Bag tacking position		When the manual mode is stopped, click the servo to reach the bag picking position according to the set parameters.
10	Put bag position		When the manual mode is stopped, click the servo to reach the bag placement position according to the set parameters.






### 3.5 Manual control interface

Mode: not connected    Status: not connected











#### Manual Control



Before simple manual operation can be performed in the manual mode of the device, debugging parameters need to be set, such as the electric forward and reverse and parameter setting of the servo motor.

NO.	Description	Refer to picture	Explanation
1	Box feed cylinder		opening and closing of delivery box cylinder.
2	Box clamp A		Out-of-box clamp A belt action.
3	Box clamp B		Out-of-box clamp B belt action.
4	Box output belt		out-of-box belt action.
5	Left ear		the opening and closing of the left closed ear cylinder.

	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	25 / 110

6	Right ear		opening and closing of the right closed ear cylinder.
7	Left folding cover		opening and closing of the left folding cover cylinder.
8	Right folding cover		the opening and closing of the right folding cover cylinder.
9	Left folded tongue		opening and closing of the left-fold tongue cylinder.
10	Right folded tongue		opening and closing of the right-folded tongue cylinder.
11	Left sealed box		opening and closing of the left sealing box cylinder.
12	Right sealed box		opening and closing of the right sealing box cylinder.
13	Left telescopic cylinder		opening and closing of the left telescopic cylinder.
14	Right telescopic cylinder		opening and closing of the right telescopic cylinder.
15	Vacuum pump		action of vacuum pump.

### 3.6 Parameter setting interface

It is used to modify the operating parameters of the equipment (**modified by professionals**). All the offsets are filled in according to the previous successful record on the workstation. Generally, it is enough to follow the factory settings, and it is not necessary to change it.

Mode: not connected    Status: not connected

### Parameter Setting 1

Angle    ##### °

	Starting Angle	End Angle	offset		Starting Angle	End Angle	offset	
Open box suction cup	##### °	##### °	#####	Left folded tongue	##### °	##### °	#####	Parameter1 Parameter2 Parameter13
Open the box and blow back	##### °	##### °		Right folded tongue	##### °	##### °	#####	
Box suction cup	##### °	##### °		Workstation bag pressing	##### °	##### °	#####	
Box back blowing	##### °	##### °		Workstation material pushing	##### °	##### °	#####	
Left Close ear	##### °	##### °	#####	Right ear cylinder	##### °	##### °		
Right close ear	##### °	##### °	#####	Left ear cylinder	##### °	##### °		
Left Close box	##### °	##### °	#####	Workstation material pushing	##### °	##### °		
Right close box	##### °	##### °	#####	Pushing servo offset	##### °	##### °	#####	
Left folding cover	##### °	##### °	#####					
Right folding cover	##### °	##### °	#####					

Main screen
Manual Control
Servo control
Parameter
I/O
Recipe
Function settings
LogIn
Fault monitoring

Mode: not connected    Status: not connected

### Left bag retrieval      Right bag retrieval

Angle    ##### °      Angle    ##### °

Left bag retrieval			Right bag retrieval			
	Starting Angle	End Angle		Starting Angle	End Angle	
Suction cup A	##### °	##### °	Suction cup A	##### °	##### °	Parameter1 Parameter2 Parameter13
Blow back A	##### °	##### °	Blow back A	##### °	##### °	
Suction cup B	##### °	##### °	Suction cup B	##### °	##### °	
Blow back B	##### °	##### °	Blow back B	##### °	##### °	
Material testing A	##### °	##### °	Material testing A	##### °	##### °	
Material testing B	##### °	##### °	Material testing B	##### °	##### °	
Number of bags taken	##### pc		Bag placement offset	#####		
			Number of bags taken	##### pc		
<div style="display: flex; justify-content: space-around;"> <span style="background-color: red; color: white; padding: 2px;">Pick up the bag Test shutdown</span> <span style="background-color: red; color: white; padding: 2px;">Bag retrieval process Deactivate</span> </div>			<div style="display: flex; justify-content: space-around;"> <span style="background-color: red; color: white; padding: 2px;">Bag retrieval process Deactivate</span> <span style="background-color: red; color: white; padding: 2px;">Automatic boxing</span> </div>			
<div style="display: flex; justify-content: space-around;"> <span>Forward</span> <span>Backward</span> </div>			<div style="display: flex; justify-content: space-around;"> <span>Forward</span> <span>Backward</span> </div>			

Main screen
Manual Control
Servo control
Parameter
I/O
Recipe
Function settings
LogIn
Fault monitoring

Mode: not connected    Status: not connected

### Parameter Setting 3

Pushing material and pressing bag down time       Pushing material and pressing bag down time

Waiting time for the material to be pushed in place

Output box conveying speed

Pushing material and pressing bag down time

Pushing material and pressing bag down time

Pushing material and pressing bag down time

Main screen
Manual Control
Servo control
Parameter
I/O
Recipe
Function settings
LogIn
Fault monitoring

Parameter1
Parameter2
Parameter13

## 3.7 Input information interface

Mode: not connected    Status: not connected

describe	address	state	describe	address	state
Material inspection fiber	I 0.0	<input type="radio"/>	Feed servo B origin	I 1.0	<input type="radio"/>
Missing box detection	I 0.1	<input type="radio"/>	Safety Gate 1	I 1.1	<input type="radio"/>
Successfully retrieved the optical fiber from the box	I 0.2	<input type="radio"/>	Safety Gate 2	I 1.2	<input type="radio"/>
Pushing material obstructs magnetic opening	I 0.3	<input type="radio"/>	Safety Gate 3	I 1.3	<input type="radio"/>
Pushing material and bag pressing cylinder up position	I 0.4	<input type="radio"/>	Safety Gate 4	I 1.4	<input type="radio"/>
Box servo A origin	I 0.5	<input type="radio"/>	Safety Gate 5	I 1.5	<input type="radio"/>
Box servo B origin	I 0.6	<input type="radio"/>	Safety Gate 6	I 1.6	<input type="radio"/>
Feed servo A origin	I 0.7	<input type="radio"/>	Safety Gate 7	I 1.7	<input type="radio"/>

Input
Output

◀
▶

Main screen
Manual Control
Servo control
Parameter
I/O
Recipe
Function settings
LogIn
Fault monitoring

Mode: not connected Status: not connected

describe	address	state	describe	address	state
Safety Gate 8	I 2.0	<input type="radio"/>	Less box photoelectric2	I 3.0	<input type="radio"/>
start	I 2.1	<input type="radio"/>	Box output belt toEmergency Stop	I 3.1	<input type="radio"/>
stop	I 2.2	<input type="radio"/>		I 3.2	<input type="radio"/>
reset	I 2.3	<input type="radio"/>		I 3.3	<input type="radio"/>
EMERGENCY STOP	I 2.4	<input type="radio"/>		I 3.4	<input type="radio"/>
Hand held box jog	I 2.5	<input type="radio"/>		I 3.5	<input type="radio"/>
Emergency stop of handheld box	I 2.6	<input type="radio"/>		I 3.6	<input type="radio"/>
Air pressure detection	I 2.7	<input type="radio"/>		I 3.7	<input type="radio"/>

Main screen
Manual Control
Servo control
Parameter
I/O
Recipe
Function settings
LogIn
Fault monitoring

Mode: not connected Status: not connected

describe	address	state	describe	address	state
	I 4.0	<input type="radio"/>	Left bag counting photoelectric	I 5.0	<input type="radio"/>
	I 4.1	<input type="radio"/>	Right bag counting photoelectric	I 5.1	<input type="radio"/>
	I 4.2	<input type="radio"/>	Left material rack shortage detection	I 5.2	<input type="radio"/>
	I 4.3	<input type="radio"/>	Right material rack shortage detection	I 5.3	<input type="radio"/>
	I 4.4	<input type="radio"/>	Pressing cylinder Original Position Magnetic Open	I 5.4	<input type="radio"/>
	I 4.5	<input type="radio"/>	Pushing cylinder Original Position Magnetic Open	I 5.5	<input type="radio"/>
	I 4.6	<input type="radio"/>	Safety Gate 9	I 5.6	<input type="radio"/>
	I 4.7	<input type="radio"/>	Safety Gate 10	I 5.7	<input type="radio"/>

Main screen
Manual Control
Servo control
Parameter
I/O
Recipe
Function settings
LogIn
Fault monitoring

Mode: not connected    Status: not connected

describe	address	state	describe	address	state
Left bagA Negative Pressure Detection	I 6.0				
Left bagB Negative Pressure Detection	I 6.1				
Right bagA Negative Pressure Detection	I 6.2				
Right bagB Negative Pressure Detection	I 6.3				
Left bag Telescopic Cylinder Retract Position	I 6.4				
Manual packing button	I 6.5				
Emergency stop button at feeding station	I 6.6				
Right bag Telescopic Cylinder Retract Position	I 6.7				

Main screen
Manual Control
Servo control
Parameter
I/O
Recipe
Function settings
LogIn
Fault monitoring

PLC input point information, when the input indicator light is gray, the corresponding input has no signal access, otherwise there is input.

### 3.8 Output information interface

Mode: not connected    Status: not connected

describe	address	state	describe	address	state
Step A for output the box	Q 0.0		Pushing bag cylinder	Q 1.0	
Step B for output the box	Q 0.1		Box delivery cylinder	Q 1.1	
	Q 0.2		Box suction cup suction box	Q 1.2	
	Q 0.3		Box suction cup blowback	Q 1.3	
red light	Q 0.4		Forming suction cup suction box	Q 1.4	
green light	Q 0.5		Forming suction cup blowback	Q 1.5	
yellow light	Q 0.6		Out of box belt	Q 1.6	
buzzer	Q 0.7			Q 1.7	

Main screen
Manual Control
Servo control
Parameter
I/O
Recipe
Function settings
LogIn
Fault monitoring

Mode: not connected    Status: not connected

describe	address	state	describe	address	state
Excessive bag pushing A cylinder	Q 2.0		Left sealing box cylinder	Q 3.0	
Excessive bag pushing B cylinder	Q 2.1		Right sealing box cylinder	Q 3.1	
Left ear cylinder	Q 2.2			Q 3.2	
Right ear cylinder	Q 2.3			Q 3.3	
Left folding cylinder	Q 2.4			Q 3.4	
Right folding cover cylinder	Q 2.5			Q 3.5	
Left folding tongue cylinder	Q 2.6			Q 3.6	
Right folding tongue cylinder	Q 2.7			Q 3.7	









Main screen
Manual Control
Servo control
Parameter
I/O
Recipe
Function settings
LogIn
Fault monitoring

Mode: not connected    Status: not connected

describe	address	state	describe	address	state
	Q 4.0		Left bag suction cup A	Q 5.0	
	Q 4.1		Left bag suction cup blowback A	Q 5.1	
	Q 4.2		Left bag suction cup B	Q 5.2	
	Q 4.3		Left bag suction cup blowback B	Q 5.3	
	Q 4.4		Right bag suction cup A	Q 5.4	
	Q 4.5		Right bag suction cup blowback A	Q 5.5	
	Q 4.6		Right bag suction cup B	Q 5.6	
	Q 4.7		Right bag suction cup back blowing B	Q 5.7	

Main screen
Manual Control
Servo control
Parameter
I/O
Recipe
Function settings
LogIn
Fault monitoring

Mode: not connected    Status: not connected

describe	address	state	describe	address	state
Pressure cylinder	Q 6.0				
Pushing cylinder	Q 6.1				
	Q 6.2				
Left bag Telescopic Cylinder	Q 6.3				
Right bag Telescopic Cylinder	Q 6.4				
	Q 6.5				
Vacuum pump	Q 6.6				
	Q 6.7				

Main screen	Manual Control	Servo control	Parameter	I/O	Recipe	Function settings	LogIn	Fault monitoring
-------------	----------------	---------------	-----------	-----	--------	-------------------	-------	------------------

PLC output point information, when the input indicator light is gray, there is no output, otherwise there is output.

### 3.9 Function Settings Interface

Mode: not connected    Status: not connected

#### Function settings

Buzzer is blocked

Automatic boxing

Stop feeding

Air pressure detection is blocked

Stop feeding

Stop feeding

The safety door is blocked











Failed to retrieve the box and deactivated

Continuous suction box shielding

Failed to retrieve the box and deactivated

Main screen	Manual Control	Servo control	Parameter	I/O	Recipe	Function settings	LogIn	Fault monitoring
-------------	----------------	---------------	-----------	-----	--------	-------------------	-------	------------------

	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	32 / 110

NO.	Description	Refer to picture	Explanation
1	The buzzer has been blocked		Press this button, and the fault will not issue an audio alarm. Status abnormalities will not trigger the alarm (use with caution).
2	Air pressure detection has been shielded		Press this button, air pressure detection will be disabled, and abnormal air source pressure will not trigger the alarm (use with caution).
3	The security door has been blocked		Press this button, the security door will be disabled, and the security door will not trigger the alarm when it is opened when running (use with caution).
4	Continuous suction box shielding		Press this button, the suction box will not be judged by whether there is material, and the box will continue to be removed.
5	Automatic boxing		Press this button, and the boxing action will no longer be completed automatically.
6	Deactivation of feeding		Press this button, and the feeding action will stop.
7	Disabled failure to pick up the box		Press this button, and the failure to pick up the box will not trigger the alarm.
8	Deactivation of feeding and unloading		Press this button, and the feeding and unloading action will stop.
9	Deactivation of the left bag		Press this button, and the action of taking the left bag will stop.
10	Right bag removal disabled		Press this button, and the right bag removal action will stop.

### 3.10 Recipe management interface

Mode: not connected    Status: not connected

#### Recipe management

Recipe Name:  Number:

Data record name:  Number:

Item Name	price
Recipe Number	0





Formula successfully written

Formula read successful


Use formula number

Writing and reading recipes  
must be done within  
Conducted in a stopped state

Main screen
Manual Control
Servo control
Parameter
I/O
Recipe
Function settings
LogIn
Fault monitoring

NO.	Description	Refer to picture	Explanation
1	Formula name		self-defined formula name.
2	Data record name		self-defined recipe data name.
3	Read the recipe operation		Select 'Use Recipe Number' and press and hold the read the recipe button for 1 second, and the data in the recipe will be restored to the specified variable.
4	Write to the recipe operation		Select 'Use Recipe Number' and press and hold the write to the recipe button for 1 second, and the data in the parameter variable will be saved in the specified formula number.

	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	34 / 110



From left to right: create a new record name, delete the data of the current formula, and rename the current data name.

## 4. Fault information and handling methods

### 4.1 Fault information interface **Figure4-1-1**




Figure 4-1-1

Fault interface: Fault monitoring interface to view the current alarm information

Enter the alarm message bar of the fault monitoring interface as shown in Figure 4-1-1

Some faults can be reset by the "Fault Clear" button.

	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	35 / 110

## 4.2 HMI fault information list

NO.	Text	Explanation
1	Compressed air pressure low	When the pressure sensor detects that the air source pressure remains consistently below the preset value, the system triggers an alarm.
2	Feeding B servo failure	The feeding B servo system has an abnormality, resulting in the inability to execute the control command normally and triggering an alarm.
3	Pushing servo failure	The pushing servo system is abnormal, resulting in the inability to execute control instructions normally and triggering an alarm.
4	Box take servo failure	The box picking servo system is abnormal, causing the control command to be unable to be executed normally and triggering an alarm.
5	Box receiving servo failure	The box receiving servo system has an abnormality, resulting in the inability to execute control commands normally and trigger an alarm.
6	Servo fault with box A	The servo system with box A has an abnormality, resulting in the inability to execute the control command normally and trigger an alarm.
7	Servo fault with box B	The servo system of Box B has malfunctioned, preventing the execution of control instructions normally and triggering an alarm.
8	Virtual spindle fault	If there are problems with the software logic, signal transmission or interconnection of the multi-axis collaborative system, it will result in the failure of multi-axis synchronization or trajectory control.
9	Feeding A servo torque exceeds the limit	The torque output by the 送料 A servo system exceeded the preset value, triggering a protective alarm in the system.
10	Feeding B servo torque exceeds the limit	The torque output by the feeding B servo system exceeds the preset value, triggering a protective alarm in the system.
11	Pushing servo torque exceeds the limit	The torque output by the feeding servo system exceeded the preset value, triggering a protective alarm in the system.
12	Box taking servo torque exceeds the limit	The torque output by the box servo system exceeded the preset value, triggering a protective alarm of the system.

	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	36 / 110

13	Box receiving servo torque exceeds the limit	The torque output by the receiving box servo system exceeded the preset value, triggering a protective alarm of the system.
14	Box A servo torque exceeds the limit	The torque output by the servo system of Box A exceeded the preset value, triggering a protective alarm in the system.
15	Box B servo torque exceeds the limit	The torque output by the Box B servo system exceeded the preset value, triggering a protective alarm in the system.
16	Delivery bag A servo failure	The servo system of bag A has malfunctioned, preventing it from properly executing the control instructions and triggering an alarm.
17	Delivery bag B servo failure	The servo system of Bag B has malfunctioned, preventing it from properly executing control instructions and triggering an alarm.
18	Bag A servo malfunction	The servo system of bag A has malfunctioned, preventing it from properly executing the control instructions and triggering an alarm.
19	Bag B servo malfunction	The servo system of bag B has malfunctioned, preventing it from properly executing the control instructions and triggering an alarm.
20	Handheld box emergency stop pressed	The emergency stop button on the portable operation handheld box was activated.
21	Emergency stop pressed	The emergency stop device in the safety system that is fixed to the equipment was activated.
22	The safety door1 has been opened	The safety interlock device 1 for isolating and protecting the dangerous areas of personnel and equipment was activated, triggering an alarm.
23	The safety door2 has been opened	The safety interlock device 2 for isolating and protecting the dangerous areas of personnel and equipment was activated, triggering an alarm.
24	The safety door3 has been opened	The safety interlock device 3 for isolating and protecting the dangerous areas of personnel and equipment was activated, triggering an alarm.
25	The safety door4 has been opened	The safety interlock device 4 for isolating and protecting the dangerous areas of personnel and equipment was activated, triggering an alarm.
26	The safety door5 has been opened	The safety interlock device 5 for isolating and protecting the dangerous areas of personnel and equipment was activated, triggering an alarm.

	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	37 / 110

27	The safety door6 has been opened	The safety interlock device 6 for isolating and protecting the dangerous areas of personnel and equipment was activated, triggering an alarm.
28	The safety door7 has been opened	The safety interlock device 7 for isolating and protecting the dangerous areas of personnel and equipment was activated, triggering an alarm.
29	The safety door8 has been opened	The safety interlock device 8 for isolating and protecting the dangerous areas of personnel and equipment was activated, triggering an alarm.
30	The safety door9 has been opened	The safety interlock device 9 for isolating and protecting the dangerous areas of personnel and equipment was activated, triggering an alarm.
31	The safety door10 has been opened	The safety interlock device 10 for isolating and protecting the dangerous areas of personnel and equipment was activated, triggering an alarm.
32	Delivery bag A servo torque exceeds the limit	The torque output by the servo system of bag A exceeded the preset value, triggering a protective alarm in the system.
33	Delivery bag B servo torque exceeds the limit	The torque output by the Bag B servo system exceeded the preset value, triggering a protective alarm in the system.
34	The servo torque of bag A exceeds the limit	The torque output by the servo system of bag A exceeded the preset value, triggering a protective alarm of the system.
35	The servo torque of bag B exceeds the limit	The torque output by the Bag B servo system exceeded the preset value, triggering a protective alarm of the system.
36	Box taking and forming failed	When it is detected that the box body grasping process or the box body shape formation process does not meet the standard requirements, a protective alarm is triggered.
37	Pressure cylinder malfunction	The pressurizing cylinder failed to complete the extension and retraction actions as per the instructions, or the action process was sluggish or misaligned, triggering an alarm.
38	Pushing cylinder malfunction	The push material cylinder failed to complete the extension and retraction actions as per the instructions, or the action process was sluggish or misaligned, triggering an alarm.
39	Pushing bag cylinder	The pusher and bag press cylinder failed to complete the extension and retraction actions as per the

	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	38 / 110

	malfunction	instructions, or the action process was sluggish or misaligned, triggering an alarm.
40	Out box emergency stop pressed	The emergency stop device installed in the safety system of the feeding area was activated.
41	Feeding emergency stop pressure	The emergency stop device installed in the safety system at the exit conveyor belt was activated.
42	The servo torque of Left box Up down exceeds the limit	The emergency stop device fixed in the safety system at the exit conveyor belt was activated. The torque output by the left bag retrieval lifting servo system exceeded the preset value, triggering a protective alarm of the system.
43	Left box Up down servo malfunction	The left bag lifting and lowering servo system malfunctioned, preventing the normal execution of control instructions and triggering an alarm.
44	The servo torque of Right box Up down exceeds the limit	The torque output by the right bag lifting and lowering servo system exceeded the preset value, triggering a protective alarm of the system.
45	Right box Up down servo malfunction	The right bag lifting and lowering servo system has malfunctioned, preventing the normal execution of control instructions and triggering an alarm.

### 4.3 HMI fault information description

condition	solution
Emergency stop	When the "Emergency Stop" button is pressed, HMI displays the alarm text.
Low air pressure	If the air pressure is insufficient, check the gas source.
Security door switch alarm	The security door is opened, and the security door can be closed.
Virtual axis failure	Restart the PLC and click the "Clear Fault" button. If you still report a fault, please contact the administrator.
Servo failure	Query the servo fault manual
Servo torque exceeds the	If there is any obstacle within the motor rotation radius, please remove it. If there is no possibility of increasing the torque of the synchronous

	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	39 / 110

limit	belt, please increase the servo torque limit appropriately.
Cylinder failure	When the cylinder is moving, the magnetic switch is not sensed within the specified time, and it is determined that the cylinder expansion and contraction is faulty.

## 5. Servo drive fault code query table

### 5.1 Faults and Warnings

Faults and warnings are divided into the following three levels based on severity: No.1 > No.2 > No.3.

■ No. 1 non-resettable fault

No. 1 resettable fault

No. 2 resettable fault

No. 3 resettable warning

"Resettable" means the keypad stops displaying the fault/warning once receiving the reset signal.

To reset a fault/warning, use one of the following two methods:

Set 200D-02h to 1 (Fault reset).

Set the rising edge of bit7 of the control word 0x6040 through the host controller.

To reset a No. 1 or No. 2 fault, turn off the S-ON signal and send a fault reset signal.

For No. 3 warnings, the servo drive resets warnings automatically after the warning source is cleared.

#### Related parameter

Para. No.	Name	Value Range	Function	Setting Condition	Effective Time	Default Value
200Dh 02h	Fault reset	0: No operation 1: Reset the fault and warning	Used to stop the keypad from displaying the fault/warning when a resettable fault/warning occurs. After fault/warning reset, 200Dh-02h is	At stop	Immediately	0

	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	40 / 110

			restored to 0 (No operation) immediately.			
--	--	--	---	--	--	--

### Solutions to faults and warnings occurred upon start

Start Process	Fault Symptom	Cause	Confirming Method
Switch on the control power supply (L1C, L2C) and main power supply (L1, L2, L3)	The LED neither lights up nor displays "ry".	1. The voltage of the control circuit power supply is abnormal.	Check whether the value of H0B-63 is 1. Measure the AC voltage between L1C and L2C
		2. Phase loss occurs on the input power supply.	Check whether the value of H0B-63 is 2. Voltage must be present in all the phases of a three-phase 380 V power supply.
		3. The voltage of the main circuit power supply is abnormal.	Check whether the value of H0B-63 is 3. <ul style="list-style-type: none"> <li>◆ For single-phase 220 V models, measure the AC voltage between L1 and L2. The keypad displays "nr" when the DC bus voltage amplitude (between terminals P and N) of the main circuit power supply is lower than 235 V.</li> <li>◆ For three-phase 220 V/380 V models, measure the AC voltage among L1, L2, and L3. The keypad displays "nr" when the DC bus voltage amplitude (between terminals P and N) of the main circuit power supply is lower than 235 V/451 V.</li> </ul>

	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	41 / 110

		4. The servo drive is faulty.	-				
	The keypad displays	See "6.3 Solutions to Faults" and "6.4 Solutions to Warnings" for solutions. "Exxx.x".					
	The keypad displays "ry" when preceding faults are cleared						
Fault	Display	Name	type	Rest	Fault Range	Error Code (603Fh)	Auxiliary Code (203Fh)
E101	E101.0	System parameter error	No.1	No	Servo drive fault	0x6320	0x01010101
	E101.1	2000h/2001h parameter error	No.1	No	Servo drive fault	0x6320	0x01010101
E102	E102.0	FPGA communication initialization error	No.1	No	Servo drive fault	0x7500	0x01020102
	E102.8	Software version mismatch	No.1	No	Servo drive fault	0x7500	0x01020102
E104	E104.1	MCU operation timeout	No.1	No	Servo drive fault	0x7500	0x11040104
	E104.2	Current loop operation timeout	No.1	No	Servo drive fault	0x7500	0x11040104
	E104.4	MCU reference update timeout	No.1	No	Servo drive fault	0x7500	0x11040104
E108	E108.0	Parameter write error	No.2	Yes	Servo drive fault	0x5530	0x01080108
	E108.1	Parameter write error	No.2	Yes	Servo drive fault	0x5531	0x01080108

<b>VANCKII</b>	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	42 / 110

	E108.2	Invalid check on data written in EEPROM	No.2	Yes	Servo drive fault	0x5532	0x01080108
	E108.3	Invalid check on data written in EEPROM	No.2	Yes	Servo drive fault	0x5533	0x01080108
E120	E120.0	Unknown encoder type	No.1	No	Axis fault	0x7122	0x01200120
	E120.1	Unknown encoder type	No.1	No	Axis fault	0x7122	0x01200120
	E120.2	Unknown encoder type	No.1	No	Axis fault	0x7122	0x01200120
	E120.5	Motor current and drive current mismatch	No.1	No	Axis fault	0x7122	0x01200120
	E120.6	FPGA and motor model mismatch	No.1	No	Axis fault	0x7122	0x01200120
E122	E122.0	Multi-turn absolute encoder setting error	No.2	Yes	Axis fault	0x6320	0x01220122
	E122.1	Different DIs assigned with the same function	No.2	Yes	Axis fault	0x6320	0x01220122
	E122.3	Upper limit invalid	No.2	Yes	Axis fault	0x6320	0x01220122

	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	43 / 110

E136	E136.0	Encoder parameter error	No.1	No	Axis fault	0x7305	0x01360136
	E136.1	Encoder communication error	No.1	No	Axis fault	0x7305	0x01360136
E140	E140.0	Encryption chip check error	No.1	No	Servo drive fault	0x0140	0x0140
	E140.1	Encryption chip check failure	No.1	No	Servo drive fault	0x0140	0x0140
E150	E150.0	STO signal input protection activated	No.1	Yes	Servo drive fault	0x0150	0x01500150
	E150.1	STO signal input error	No.1	Yes	Servo drive fault	0x0150	0x01500150
	E150.2	Abnormal voltage detected	No.1	Yes	Servo drive fault	0x0150	0x01500150
	E150.3	STO upstream optocoupler detection failure	No.1	Yes	Servo drive fault	0x0150	0x01500150
	E150.4	PWM Buffer detection failure	No.1	Yes	Servo drive fault	0x0150	0x01500150
E201	E201.0	Phase-P overcurrent	No.1	No	Servo drive fault	0x2312	0x12010201
	E201.1	Phase-U overcurrent	No.1	No	Axis fault	0x2312	0x12010201
	E201.2	Phase-V overcurrent	No.1	No	Axis fault	0x2312	0x12010201

E201.4	Phase-N overcurrent	No.1	No	Servo drive fault	0x2312	0x12010201
--------	---------------------	------	----	-------------------	--------	------------

## 5.2 Communication Faults and Warning Codes

Fault	Display	Name	type	Rest	Fault Range	Error Code (603Fh)	Auxiliary Code (203Fh)
E208	E208.0	MCU position reference updated frequently	No.1	Yes	Axis fault	0x0208	0x02080208
	E208.2	Encoder communication timeout	No.1	Yes	Axis fault	0x0208	0x02080208
	E208.3	Current sampling fault	No.1	Yes	Axis fault	0x0208	0x02080208
	E208.4	FPGA current loop operation timeout	No.1	Yes	Axis fault	0x0208	0x02080208
E210	E210.0	Output short-circuited to ground	No.1	No	Axis fault	0x2330	0x02100210
E234	E234.0	Runaway protection	No.1	No	Axis fault	0x0234	0x02340234
E400	E400.0	Main circuit overvoltage	No.1	Yes	Servo drive fault	0x3210	0x04000400
E410	E410.0	Main circuit undervoltage	No.1	Yes	Servo drive fault	0x3220	0x04100410
E420	E420.0	Phase loss fault	No.2	Yes	Servo drive fault	0x3130	0x04200420
E430	E430.0	Control circuit undervoltage	No.2	Yes	Servo drive fault	0x0430	0x04300430
E500	E500.0	Motor overspeed	No.1	Yes	Axis fault	0x8400	0x05000500

	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	45 / 110

	E500.1	Speed feedback overflow	No.1	Yes	Axis fault	0x8400	0x05000500
	E500.2	FPGA position feedback pulse overspeed	No.1	Yes	Axis fault	-	0x05000500
E602	E602.0	Angle auto-tuning erro	No.1	Yes	Axis fault	0x0602	0x06020602
	E602.2	Wrong UVW phase sequence detected during angle auto-tuning	No.1	Yes	Axis fault	0x0602	0x06020602
E605	E605.0	Speed upon S-ON too high	No.1	Yes	Axis fault	0x8400	0x06050605
E620	E620.0	Motor overload	No.1	Yes	Axis fault	0x3230	0x06200620
E630	E630.0	Motor stall	No.1	Yes	Axis fault	0x7121	0x06300630
E640	E640.0	IGBT over-temperature	No.1	Yes	Axis fault	0x4210	0x06400640
	E640.1	Flywheel diode over-temperature	No.1	Yes	Axis fault	0x4210	0x06400640
E650	E650.0	Heatsink over-temperature	No.1	Yes	Axis fault	0x4210	0x06400650
E660	E660.0	Air-cooled motor over-temperature	No.1	Yes	Axis fault	0x4210	0x06600660
E661	E661.0	Auto-tuned gains too low	No.2	Yes	Axis fault	0x4210	0x06610661
E731	E731.0	Encoder battery failure	No.2	Yes	Axis fault	0x0661	0x07310731
E733	E733.0	Encoder multi-turn counting error	No.2	Yes	Axis fault	0x7305	0x07330733
E735	E735.0	Encoder multi-turn counting overflow	No.2	Yes	Axis fault	0x7305	0x07350735
E740	E740.2	Absolute encoder error	No.1	No	Axis fault	0x7305	0x67400740

<b>VANCKII</b>	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	46 / 110

	E740.3	Absolute encoder single-turn calculation error	No.1	No	Axis fault	0x7305	0x67400740
	E740.6	Encoder write error	No.1	No	Axis fault	0x7305	0x67400740
E755	E755.0	Nikon encoder communication failure	No.1	No	Axis fault	-	0x07550755
E760	E760.0	Encoder over-temperature	No.2	Yes	Axis fault	0x4210	0x07600760
E765	E765.0	Nikon encoder beyond the limit	No.1	No	Axis fault	-	0x07650765
EB00	EB00.0	Position deviation too large	No.2	Yes	Axis fault	0x8611	0x1B000B00
	EB00.1	Position deviation overflow	No.2	Yes	Axis fault	0x8611	0x1B000B00
EA33	EA33.0	Encoder read/write check error	No.1	No	Axis fault	0x7305	0x0A330A33
EB01	EB01.1	Position reference increment too large for once	No.2	Yes	Axis fault	0x6320	0x1B010B01
	EB01.2	Position reference increment too large continuously	No.2	Yes	Axis fault	0x6320	0x2B010B01
	EB01.3	Reference overflow	No.2	Yes	Axis fault	0x6320	0x3B010B01
	EB01.4	EB01.4: Target position beyond upper/lower limit	No.2	Yes	Axis fault	0x6320	0x4B010B01
EE09	EE09.0	Software position limit setting error	No.2	Yes	Axis fault	0x6320	0x0E090E09
	EE09.1	Home setting error	No.2	Yes	Axis fault	0x6320	0x1E090E09
	EE09.2	Gear ratio beyond the limit	No.2	Yes	Axis fault	0x6320	0x2E090E09

	EE09.3	No synchronization signal	No.2	Yes	Axis fault	0x6320	0x3E090E09
	EE09.5	PDO mapping beyond the limit	No.2	Yes	Axis fault	0x6320	0x5E090E09
EE08	EE08.0	SYNC signal loss	No.2	Yes	Axis fault	0x0FFF	0x0E086E08
	EE08.1	Network status switchover error	No.2	Yes	Axis fault	0x0FFF	0x1E086E08
	EE08.2	IRQ loss	No.2	Yes	Axis fault	0x0FFF	0x2E086E08
	EE08.3	LAN cable connected improperly	No.2	Yes	Axis fault	0x0FFF	0x3E086E08
	EE08.4	Data frame loss protection error	No.2	Yes	Axis fault	0x0FFF	0x4E086E08
	EE08.5	Data frame transfer error	No.2	Yes	Axis fault	0x0FFF	0x5E086E08
	EE08.6	Data update timeout	No.2	Yes	Axis fault	0x0FFF	0x6E086E08
EE11	EE11.0	ESI check error	No.2	Yes	Servo drive fault	0x5530	0x0E110E11
	EE11.1	EEPROM read failure	No.2	Yes	Servo drive fault	0x5530	0x1E110E11
	EE11.2	EEPROM update failure	No.2	Yes	Servo drive fault	0x5530	0x2E110E11
EE12	EE12.0	Ether CAT external device error	No.1	No	Servo drive fault	0x0E12	0x0E120E12
EE13	EE13.0	Synchronization cycle setting error	No.2	Yes	Servo drive fault	0x6320	0x0E130E13

	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	48 / 110

EE15	EE15.0	Number of synchronization cycle errors too large	No.2	Yes	Servo drive fault	0x0E15	0x0E150E15
------	--------	--	------	-----	-------------------	--------	------------

E121	E121.0	Invalid S-ON command	No.3	Yes	Warning	0x0121	0x01210121
E600	E600.0	Inertia auto-tuning failure	No.3	Yes	Warning	0x0600	0x06000600
E601	E601.0	Homing timeout	No.3	Yes	Warning	0x0601	0x06010601
	E601.1	Home switch error	No.3	Yes	Warning	0x0601	0x16010601
	E601.2	Homing mode setting error	No.3	Yes	Warning	0x6320	0x2601E602
E730	E730.0	Encoder battery warning	No.3	Yes	Warning	0x7305	0x07300730
E900	E900.0	Emergency stop	No.3	Yes	Warning	0x0900	0x09000900
E902	E902.0	Invalid DI setting	No.3	Yes	Warning	0x6320	0x09020902
	E902.1	Invalid DO setting	No.3	Yes	Warning	0x0902	0x19020902
E908	E908.0	Model identification check byte invalid	No.3	Yes	Warning	0x0908	0x09080908
E909	E909.0	Motor overload warning	No.3	Yes	Warning	0x3230	0x09090909
E920	E920.0	Regenerative resistor overload	No.3	Yes	Warning	0x3210	0x09200920
E922	E922.0	Resistance of external regenerative resistor too small	No.3	Yes	Warning	0x6320	0x09220922

	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	49 / 110

E924	E924.0	Braking transistor over-temperature	No.3	Yes	Warning	0x3230	0x09240924
E941	E941.0	Parameter modifications not activated	No.3	Yes	Warning	0x6320	0x09410941
E942	E942.0	Parameter saved frequently	No.3	Yes	Warning	0x7600	0x09420942
E950	E950.0	Forward overtravel warning	No.3	Yes	Warning	0x5443	0x09500950
E952	E952.0	Reverse overtravel warning	No.3	Yes	Warning	0x5444	0x09520952
EA41	EA41.0	Torque ripple compensation failure	No.3	Yes	Warning	0x0A41	0x0A410A41

	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	50 / 110

## 5.3 Solutions to Faults

### ■ E101.0: System parameter error

Direct cause:

The total number of parameters changes, which generally occurs after software update.

Parameter values in groups 2002h and above exceed the limit, which generally occurs after software update.

Root Cause	Confirming Method	Solution
1. The control power voltage drops instantaneously.	Check whether the voltage drops during control power (L1C, L2C) cutoff or whether instantaneous power failure occurs	Restore system parameters to default values (2002-20h = 1), and write parameters again.
	Measure whether the voltage input to the control circuit cable during operation is within the following range: 220 V servo drive: Effective value: 220 V to 240 V Allowable deviation: - 10% to +10% (198 V to 264 V) 380 V servo drive: Effective value: 380 V to 440 V Allowable deviation: - 10% to +10% (342 V to 484 V)	Increase the power capacity or replace with a power supply of larger capacity. Restore system parameters to default values (2002 20h = 1), and write parameters again.
2. Instantaneous power failure occurs during parameter saving.	Check whether instantaneous power failure occurs during parameter saving.	Power on the system again, restore system parameters to default values (2002-20h = 1), and write parameters again.
3. The number of	Check whether	Change the write mode and

	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	51 / 110

write operations exceeds the limit.	parameters are updated frequently through the host controller.	write parameters again. If the servo drive is faulty, replace it.
4. The software has been updated.	Check whether the software has been updated	Reset the servo drive model and the servo motor model, and restore system parameters to default values (2002-20h = 1).
5. The servo drive is faulty.	If the fault persists after several times of restart and parameter initialization, the servo drive is faulty	Replace the servo drive.

■ E101.1: 2000h/2001h parameter error

Direct cause:

The total number of parameters changes, which generally occurs after software update.

Parameter values in group 2000h or 2001h exceed the limit, which generally occurs after software update.

Root Cause	Confirming Method	Solution
1. Instantaneous power failure occurs during parameter saving.	Check whether instantaneous power failure occurs during parameter saving.	Set the servo drive model (2001-0Bh) to a wrong value first and perform a power cycle, and then set the servo drive model to a correct value and perform a power cycle.

	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	52 / 110

2. Instantaneous power failure occurs during the write operation.	Check whether instantaneous power failure occurs during writing motor parameters.	Write motor parameters using the software tool
3. The software has been updated.	Check whether the software has been updated.	Set the servo drive model (2001-0Bh) to a wrong value first and perform a power cycle, and then set the servo drive model to a correct value and perform a power cycle.
4. The servo drive is faulty.	If the fault persists after repeated execution of steps 1 and 2 and multiple times of restart, the servo drive is faulty.	Replace the servo drive.

■ E102.0: FPGA communication initialization error

Direct cause:

The FPGA- or MCU-related hardware is damaged, resulting in communication failure between the MCU and FPGA.

Root Cause	Confirming Method	Solution
1. The FPGA is faulty. 2. The MCU cannot communicate with the FPGA.	The fault persists after the servo drive is powered off and on several times.	1. Confirm whether the FPGA has been upgraded. Ensure the programming is successful. 2. Replace the servo drive.

	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	53 / 110

■ E102.8: Software version mismatch

Root Cause	Confirming Method	Solution
The software version of MCU or FPGA is wrong	Check whether the MCU version (H01-00) is 9xx.x (the fourth digit displayed on the keypad is 9). Check whether the FPGA version (H01-01) is 9xx.x (the fourth digit displayed on the keypad is 9).	Contact Inovance for technical support and update to mutually matching FPGA or MCU software.

■ E104.1: MCU operation timeout

Direct cause:

The access to MCU times out

Root Cause	Confirming Method	Solution
1. The FPGA is faulty.	The fault persists after the servo drive is powered off and on several times	Replace the servo drive.
2. The communication handshake between FPGA and HOST is abnormal.		
3. Access timeout occurs between HOST and the coprocessor.		

	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	54 / 110

■ E104.2: Current loop operation timeout

Direct cause:

The operating time of the current loop exceeds the scheduling time. This fault is reported only in the commissioning stage.

Root Cause	Confirming Method	Solution
The time interval of MCU torque interrupt scheduling is abnormal.	The fault persists after the servo drive is powered off and on several times.	Replace the servo drive.

■ E104.4: Command update timeout

Direct cause: Replace the servo drive. Take the moment when entering the interrupt as the starting time. If the duration of the command-write operation in MCU is longer than the start time of the FPGA position and speed regulator, a warning will be reported.

Root Cause	Confirming Method	Solution
The interrupt time of the current loop is too long.	Check whether the interrupt time of the torque loop is too long through the software tool.	Hide unnecessary functions.

■ E108.0: Parameter write error

Direct cause: Parameter values cannot be written to EEPROM.

Root Cause	Confirming	Solution
------------	------------	----------

	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	55 / 110

	Method	
An error occurs when parameter values are read in EEPROM	Modify a certain parameter value, power off and on the servo drive again, and check whether the modified value is saved.	If the modified value is not saved and the fault persists after the servo drive is powered off and on again, replace the servo drive.

■ E108.1: Parameter read error

Direct cause:

Parameter values cannot be read in EEPROM.

Root Cause	Confirming Method	Solution
An error occurs when parameter values are read in EEPROM.	Modify a certain parameter value, power on a servo drive again, and check whether the modified value is saved	If the modified value is not saved and the fault persists after the servo drive is powered off and on again, replace the servo drive.

■ E108.2: Invalid check on data written in EEPROM

Root Cause	Confirming Method	Solution
The check on the data written in EEPROM fails.	Modify a certain parameter value, power off and on on again, replace the servo drive. Solution the servo drive again, and check whether the modified value is saved.	If the modified value is not saved and the fault persists after the servo drive is powered off and on again, replace the servo drive.

	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	56 / 110

■ E108.3: Invalid check on data read in EEPROM

Root Cause	Confirming Method	Solution
An error occurs when parameter values are read in EEPROM	Modify a certain parameter value, power off and on the servo drive again, and check whether the modified value is saved.	If the modified value is not saved and the fault persists after the servo drive is powered off and on again, replace the servo drive.

■ E120.0: Unknown encoder type

Direct cause:

The servo drive detects the encoder model during initialization upon power-on. If the encoder type does not comply with the requirements, the servo drive reports E120.0.

Root Cause	Confirming Method	Solution
The encoder model does not match the servo drive.	Check whether the encoder model is correct.	Replace the encoder.

■ E120.1: Unknown motor model

Direct cause:

The servo drive detects the motor model (H00-00) during initialization upon power-on. If the motor model does not exist, the servo drive reports E120.1.

Root Cause	Confirming Method	Solution
The motor model is set	Check whether H00-00	Set H00-00 to a proper value

	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	57 / 110

improperly.	(Motor code) is set properly.	that matches the motor model.
-------------	-------------------------------	-------------------------------

■ E120.2: Unknown drive model

Direct cause:

The servo drive detects the servo drive model (H01-10) during initialization upon power-on. If the servo drive model does not exist, the servo drive reports E120.2.

Root Cause	Confirming Method	Solution
The servo drive model is set improperly.	Check whether H01-10 (Servo drive series number) is set properly.	Set H01-10 to a proper value that matches the servo drive model.

■ E120.5: Motor current and drive current mismatch

Direct cause:

The rated output current of the servo drive is higher than the rated current of the motor.

Root Cause	Confirming Method	Solution
The internal scaling value is abnormal.	Check whether the servo drive model is correct. If the rated current of the set servo drive model is larger than the rated current of the motor, calculation overflow will occur.	Replace with a servo drive of lower rated output current or a motor with higher rated current.

	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	58 / 110

■ E120.6: FPGA and motor model mismatch

Direct cause:

1. The motor model is set improperly, causing mismatch and malfunction of the servo drive.
2. The motor model is set properly, but the motor encoder is not supported by the servo drive.

Root Cause	Confirming Method	Solution
The FPGA does not support the motor encoder.	Check whether the motor encoder is supported by the FPGA version (H01-01).	Update FPGA software or replace the motor encoder.

■ E122.0: Multi-turn absolute encoder setting error

Root Cause	Confirming Method	Solution
The motor does not match the absolute position mode or the motor code is set improperly.	Check the motor nameplate to see whether the motor is equipped with an absolute encoder. Check whether 200D-01h (Motor code) is set properly.	Set 200D-01h (Motor code) correctly according to the motor nameplate or replace with a matching motor.

■ E122.1: Different DIs assigned with the same function

Root Cause	Confirming Method	Solution
1. The same function is assigned to different DIs	View 2003-03h, 2003-05h...2003-15h, 2017-01h, and	Assign different DI functions to parameters that have been assigned with the same DI

	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	59 / 110

	2017-03h...2017-1Fh to check whether they are assigned with the same DI function No.	function. To enable such assignments, restart the control circuit or switch off the S-ON signal and send a "RESET" signal.
2. The DI function No. exceeds maximum setting number allowed for DI functions.	Check whether the MCU software has been updated.	Restore system parameters to default values (2002-20h = 1) and power off and on the servo drive again.

■ E122.3: Upper limit invalid

Root Cause	Confirming Method	Solution
The upper limit value of the mechanical single-turn position exceeds 231 in the absolute position rotation mode.	Check the mechanical gear ratio setpoint, the upper limit of the mechanical single-turn position, and the electronic gear ratio in the absolute position rotation mode (H02-01 = 2).	Reset the mechanical gear ratio, the upper limit of mechanical single-turn position, and the electronic gear ratio to ensure the upper limit of the mechanical single-turn position (reference range) does not exceed 231.

■ E136.0: Encoder parameter error

Direct cause:

When the servo drive reads parameters in the encoder ROM, no parameters are saved or parameter values are inconsistent with the expected values.

Root Cause	Confirming Method	Solution
1. The servo drive model does not match the servo motor model	View the servo drive and servo motor nameplates to check whether the devices	Replace with the mutually-matching servo drive and servo motor.

	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	60 / 110

	used are Inovance SV630N series servo drive and servo motor.	
2. A parameter check error occurs or no parameter is stored in the serial incremental encoder ROM.	<p>Check whether the encoder cable provided by Inovance is used. For cable specifications, see "1.4 Cable Models". Ensure the cable is intact and in good contact at both ends. Measure signals PS+, PS-, +5V and GND at both ends of the encoder cable and observe whether signals at both ends are consistent. For signal definitions, see "3 Wiring".</p>	<p>Use the encoder cable provided by Inovance. Ensure the cable is connected to the motor securely and tighten the screws on the servo drive side. Use a new encoder cable if necessary. Do not bundle encoder cables together with power cables (RST, UVW). Lay encoder cables and power cables through different routes</p>
3. The servo drive is faulty.	The fault persists after servo drive is powered off and on again.	Replace the servo drive.

■ E136.1: Encoder communication error

Direct cause:

1. The encoder cable is disconnected.
2. The encoder communication suffers from interference

Root Cause	Confirming Method	Solution
A fault occurs on the communication	Observe the value of H0B-28 to see whether it is not 0	Check whether the encoder cable is connected properly.

	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	61 / 110

between FPGA and the motor encoder during initialization upon power-on.		Check whether the motor model is set properly. Check whether H01-00 (MCU software version) and H01-01 (FPGA software version) are the correct ones
---	--	---

■ E140.0: Encryption chip check error

Direct cause:

The check on the encryption chip fails.

Direct cause:

The check on the encryption chip fails.

Root Cause	Confirming Method	Solution
The encryption software is not programmed.	Power off and on again to check whether the fault persists.	Contact Inovance to program the encryption software again.

■ E140.1: Encryption chip check failure

Direct cause:

The check on the encryption chip fails.

Root Cause	Confirming Method	Solution
The key of the encryption chip is incorrect, causing failure in decrypting the Renesas chip.	<ol style="list-style-type: none"> <li>1. Check the software version. Check whether encryption is programmed in the servo drive.</li> <li>2. Check whether the encryption chip is abnormal.</li> </ol>	Power off and on the servo drive again. If the fault persists, contact Inovance for maintenance.

	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	62 / 110

■ E150.0: STO signal input protection activated

Direct cause:

The STO input protection applies (safety state).

Root Cause	Confirming Method	Solution
1. The STO is activated.	Check whether the STO function is activated.	There is no need to take any actions. Clear the fault through the fault reset function after the STO terminal is restored.
2. The STO power supply is abnormal.	Check whether the 24 V power supply of the STO works normally	Measure the 24 V power supply of the STO to check whether it is stable. Tighten the cables that are loose or disconnected.
3. The STO is inactive.	The fault persists after preceding actions are taken.	Replace the servo drive.

<b>NOTE</b>	When H0A-21 is set to 0, STO displays the STO state. When H0A-21 is set to 1, STO displays E150.0.
-------------	--

### Circuit diagram

Reference Electrical Principle

	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	63 / 110

## 6. Paper box requirements

### 6.1 Shape and size

In order to minimize the downtime of the machine during operation, it is very important to keep the materials of the cartons the same as the maintenance of the machine, and to keep them at an excellent standard level. Some important and useful information about the carton is explained here.

1.The thickness of the required paper for some specific paper boxes should depend on the following factors, such as the type of paper box, the style of the paper box to be made, the weight of the contents, the direction of the paper fibers, etc. The strength of the paper depends on the type of paper, thickness, basic sheet weight, etc. It should be remembered that when the thickness of the paper is doubled, its strength increases by eight times, which is always greater in the direction of the machine of the paper than in the horizontal direction. Therefore, the direction of the machine should always run across the longest folding line, which will help to minimize the wrinkle phenomenon in the box-making process. The type, thickness and strength of the paper must be determined by the price and function. The basic weight of the paper should not be less than 275 grams per square meter.

2.The crease is made on the carton blank, so that it can provide a carton blank with appropriate strength and a folding line that is easy and accurately folded. Making creases is one of the most important operations in the manufacture of cartons. In order to have good performance, there must be a correct relationship between the fold depth/width and the strength of the paper. The relative cracking force of the crease must be 60% of that of the no creases carton. Too shallow creases will cause the lining of the paper to crack, too narrow creases will give pressure to bulge the ridge, too deep creases will cause the paper body to crack, and too wide creases will give wrinkles inside the fold. Poor edge cutting operation will produce powder and connect the pieces to each other. Narrow creases are preferred, but the lining of the paper must not be broken. All creases must have full depth on the full length and meet correctly at all intersections. The width of the crease is about 0.5~0.8mm.

3.Please do not use the same-side design for the color box. The same-side design conflicts with the existing equipment (box folding machine), and additional manpower must be added to fold the box manually.

4.It is important to make the paper pieces flat, because the deformed paper box blanks are stacked, which is difficult to operate, and it is also difficult to feed neatly and


	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	64 / 110

smoothly into the processing box. They will also be crowded and stuck in the guide rail and become difficult to shape. Bent and rolled pieces of paper often have bad effects in operation.


5. When the cardboard box comes in, it needs to be pre-folded in advance. A carton of excellent quality should be easy to open with a little pressure with your fingers and thumb. Cardboard boxes that are difficult to open by hand, or cardboard boxes that are not easy to close, will inevitably cause trouble on the machine. When the materials used in cartons and cartons are of excellent quality, the faster the manufacturing speed, the more important it is.

6. After the product is put into the carton, the size of the carton cannot be changed, and there should be a gap at the top and bottom sealing of the box to facilitate the sealing of the box.

7. If there is an inner lining in the box, the inner lining cannot affect the sealing of the box, and there must be a gap for the sealing box. Reference as shown in the figure.




When sealing the box, the gap of the tongue should be 1~1.2 times that of the paper. If the gap is too small, the box will not be sealed, and the sub-grade rate of the box folding machine will increase. The size of the cardboard box edge and the folding page edge is 0.6, as shown in the figure.




The length of the folding pages on the left and right sides should not exceed 1/2 of the front width of the carton, the length of the tongue is 12mm, the rounded corner is 10,

	<b>Operation manual</b> <b>操作手册</b>	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	65 / 110

the tongue length is 15, the rounded corner is 12, the width of the open buckle tongue is the width of the box minus the width of two pages of paper, and the width of the hidden buckle tongue is the same as the width of the inside of the carton. If it is too long, it will lead to the box folding machine. Rise. As shown in the picture




The short tongue and upper and lower flaps in the box in the form of dispensing will be slightly changed. As shown in the picture




The material direction of the color box is suggested as shown in the figure.

	<b>Operation manual</b> <b>操作手册</b>	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	66 / 110




Incoming material direction

1. Design suggestions for the position of the QR code, printing code, stickers, color label, and text direction on the color box are as shown in the picture.



	<b>Operation manual</b> <b>操作手册</b>	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	67 / 110



## 6.2 Storage and use

In most cases, unevenness, curling and lifting are due to poor storage and handling or loading and unloading conditions. The carton blank should not be transported in the package, especially it should not be loaded into the package and then tied with ropes and bandaging, which will cut into the blank and cause damage. If the carton blanks are transported in a corrugated fiberboard box, they are well protected. Carton blanks should not be stored on the ground, in direct sunlight or near heat sources, and should avoid stacking such boxes to the extent that they reach high stacks. The paper used to make the carton absorbs moisture from the humid air and loses moisture when dry, thus changing its size. The temperature of the storage location also affects the size of the cardboard, because the paper is made of fibers, and these fibers do not need to shrink and elongate to each other when atmospheric conditions change, so bending and lifting occur. Unevenness is often caused by poor storage conditions.



Storage should be carried out at about 20°C and relative humidity of 60-65%, in a relatively dry environment, the paper will tend to crack, especially when folded, and the wet paper will lose its strength.

When ordering a new machine for the first carton processing, try to buy as little as possible. Sometimes the carton looks like it doesn't have any defects, but after the first trial process, some degree of defect appears. This allows corrections to be made before

	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	68 / 110

the next delivery.


The packaging of the pieces of paper should not be too tight, that is, they should not bulge after applying moderate pressure with your hands. Place a pile of paper on the table, there must be some rebound after a little pressure with your hand, and then relax. If a completely flat piece of paper does not have this resilience, poor performance often occurs in the box making machine.



## 7. Operation parameters



The parameters C-boost 8pcs during FAT tests, they are only for reference. Could be modified according to final testing material and product.



### 7.1 Cboost-8pcs



The parameters setting for Cboost-8pcs counting and cartonering packing is shown as following.























	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	75 / 110



## 7.2 Cboost-10pcs



The parameters setting for Cboost-10pcs counting and cartonering packing is shown as following.




















	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	81 / 110







### 7.3 Cboost-15pcs



The parameters setting for Cboost-15pcs counting and cartonering packing is shown as following.




















	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	88 / 110



## 7.4 Fibotax-10pcs



The parameters setting for Fibotax-10pcs counting and cartonering packing is shown as following.




















	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	94 / 110







## 7.5 Simfex-15pcs



The parameters setting for Simfex-15pcs counting and cartonering packing is shown as following.




















	<b>Operation manual</b> 操作手册	Doc. No. 文件编号	VAN256066
		Ver. No. 版本编号	V 1.0
		Page 页码	101 / 110



## 7.6 Manual line



The parameters setting for Simfex-15pcs counting and cartonering packing is shown as following.

















**Manual operation**

Warm notice:

Need take off the guard plate front of manual pusher.

