

9 channels

CH	Function	
1	Pan	0-255
2	Tilt	0-255
3	Color	
	0-139	Choose color
	140-255	Auto change from slow to fast
4	Gobo	
	0-63	Fixed gobo
	64-127	Gobo shake
	128-255	Auto change from slow to fast
5	Strobe	0-255
6	Dimmer	0-255
7	Pan&TILT	0-255
8	Auto mode	0-255 Up to adjust forward, down to adjust backward
9	Reset	250-255 (5 second)

## Specifications:

Voltage: AC110-220V, 50-60HZ

Power sumpcion : 75W

Light source : 1 pc 60W white led

Gobo: 8

Color: 8

DMX channel : 9/11CH

Control mode: sound, Master-slave, Auto, DMX

Pan: 540°

Tilt: 270°

Manuel focucus

## 60W led gobo moving head



Addr	A001-A512	512 address setting
CHnd	11CH	11 channel
	9CH	9 channel
SLnd	MAST	Master
	SL 1	Console
	SL 2	Slave
SHnd	SH 0	Effect 0 (recommend)
	SH 1	Effect 1
	SH 2	Effect 2

	SH 3	Effect 3
Soud	on	Sound mode on
	oFF	Sound mode off
SEnS	0-99	Sound sensitivity adjustment
bLAnd	bLAc	No signal go to origin
	Auto	No signal run auto mode
	Soun	No signal run sound mode
	HoLd	No signal hold on same status
LEd	OFF	5 second screen off
	ON	Display on at all times
dISP	no	Display backforward
	YES	Display forward
rPAN	no	Pan motor run forward
	YES	Pan motor run backward
rTiL	no	Tilt motor forward
REST	YES	Reset

6	Gobo	
	0-63	Fixed gobo
	64-127	Gobo shaking
	128-255	Gobo auto change slow to fast
7	Strobe	0-255
8	Dimmer	0-255
9	Pan&Tilt speed	0-255
10	Auto mode	
	0-59	Other channel function
	60-84	Sound 3
	85-109	Sound 2
	110-134	Sound 1
	135-159	Sound 0
	160-184	Sound 3
	185-209	Sound 2
	210-234	Sound 1
	235-255	Sound 0
11	Reset	250-255 (5 second)

## 11 channel

Channel	Function	Discription
1	Pan	0-255
2	Pan fine	0-255
3	Tilt	0-255
4	Tilt fine	0-255
5	Color	
	0-139	Color choose
	140-255	Auto change color slow to fast